

SEATS • CROSS REFERENCE TO OEM NUMBERS

Aftermarket Seats are multiple use replacements for the OEM part numbers listed. The Aftermarket seat, or the machine to which it is to be fitted, will likely have to be modified to mount the seat; or our Universal Adapter Plate will be needed.

The Universal Adapter Plate will aid in the mounting of seats if the OEM mounting plate is missing or damaged. This may allow the installer to avoid drilling holes in the machine cab floor or the seat, itself. The adapter plate works with all the seats stocked by Aftermarket Parts.

API 39929002

FRANKLIN - 1501814
TAMROCK - 69019426
TIMBERJACK - 810210600, 810753200

API 39935001

FRANKLIN - 1501814
TAMROCK - 69019426
TIMBERJACK - 810210600, 810753200

API 39935002

CAT - 1V2308, 8K7264
FRANKLIN - 1508808, 1504026, 1513427
RANGER - R12579578, R1938926, 1908858, 1935739, 1930624, 1572355
TIMBERJACK - 810806600, 840876300, 231367300

API 39935003

FRANKLIN - 1501814
TAMROCK - 69019426
TIMBERJACK - 810210600, 810753200

API 39974001 (Swivel kit part number 46794000 can be added as an option to this seat if the OEM seat had a turn table or swivel.)

FRANKLIN - 1511105, 1511106, 1504535, 1514204
JOHN DEERE - AT172382
RANGER - R11216, R11218
TIMBERJACK - 811140600, 811140700, 811726000, 811999300, F121152, F121341

API 39974012 (Swivel kit part number 46794000 can be added as an option to this seat if the OEM seat had a turn table or swivel.)

FRANKLIN - 1513946, 1515153
JOHN DEERE - AT177629, AT185377, AT366811, AT341833, AT407215
PRENTICE / CTR - 10061793
TIMBERJACK - F121933, F122300

API 39976004

TIGERCAT - BQ039

API 39976005

BARKO - 536-00052, 536-00681, 536-00754, 536-00918
FRANKLIN - 1511342, 1513524, 1509977, 1510513
PRENTICE - 10001141, 10002798, 10005353/10033805, 3799626
TIGERCAT - BQ006

